


NEWALL

PART # CONFIGURATION FOR

MHG-VP

SERIES INCREMENTAL LINEAR ENCODERS



These encoders are intended for use with the SCC-200 converter

Standard specifications shown in red

Measuring Lengths

- 2"
 - 4"
 - 6"
 - 8"
 - 10"
 - 12"
 - 14"
 - 16"
 - 18"
 - 20"
 - 22"
 - 24"
 - 26"
 - 28"
 - 30"
- Always order by measuring length (MHG overall length = measuring length + 7.4")
- Prefix the measuring length with 0's as necessary to get to 3 digit order code. Example: 2" is 002
- Linear Encoders include:
- Reader head with cable
 - Scale (Tube)
 - Brackets to mount the scale (Tube)
 - SCC-200 converter
- Scale (tube) mounting kit # FX00MDBR is provided
- Extension cables are sold separately. SCC-200 output cables are sold separately.
- Bracket kits to mount the reader head are sold separately

Reader Head Bracket Kits

<i>Part #</i>	<i>Description</i>
34"	UBK02 Universal Bracket Kit (Mounts one MHG and one SHG reader head)
36"	UBK03 Universal Bracket Kit (Mounts two MHG reader heads)
38"	LBK02 Lathe Bracket Kit (Mounts one MHG and one SHG reader head)
40"	LBK03 Lathe Bracket Kit (Mounts two MHG reader heads)
	QBK01 Quill Bracket Kit (Mounts one MHG reader heads)

Optional Scale (Tube) Mounting Hardware

<i>Part #</i>	<i>Description</i>
600-65340	Single End Mount for MHG scale (tube)

Setup Tube

<i>Part #</i>	<i>Description</i>
6666666	Alignment Tool for Use During Installation (Free)

NEWALL


PART # CONFIGURATION FOR

EXTENSION CABLES

for use with

SHG-VP, SHG-VS, & MHG-VP

SERIES LINEAR ENCODERS



Standard specifications shown in red

NEWALL


PART # CONFIGURATION FOR

OUTPUT CABLES

for use with

SCC-200

SIGNAL CONVERTER



Standard specifications shown in red

V 11.29.05