


## SERIES INCREMENTAL LINEAR ENCODERS



Measuring		
Lengths	- Always order by measuring length (DMG overall length = measuring length + 7.4")	
2" 4"	- Prefix the measuring length with 0's as necessary to get to 3 digit order code. Example: 2" is 002	
6"	TTOTAL CITO TIN	sasaring forigin with 0 5 as necessary to got to 5 aight order south Example: 2 15 602
8"	- Linear Encoders include reader head with cable, scale (tube), and brackets to mount the scale (tube)	
10"		
12″	<ul> <li>Scale (tube) mounting kit # FX00MDBR is provided</li> </ul>	
14"		
16"	- Extension cables are sold separately	
18"	Dragkat kita	to many the mander band are cald concretely
20″ 22″	- Bracket kits to mount the reader head are sold separately	
24"	Reader Head Bracket Kits	
26"	Part #	Description Description
28"	UBK02	Universal Bracket Kit (Mounts one DMG and one DSG reader head)
30"	UBK03	Universal Bracket Kit (Mounts two DMG reader heads)
32"	LBK02	Lathe Bracket Kit (Mounts one DMG and one DSG reader head)
34"	LBK03	Lathe Bracket Kit (Mounts two DMG reader heads)
36"	QBK01	Quill Bracket Kit (Mounts one DMG reader head)
38"		
40"	Optional Scale (Tube) Mounting Hardware	
	Part #	Description Single End Mount for DMC cools (tube)
	600-65340	Single End Mount for DMG scale (tube)
	Setup Tube	
	Part #	Description
	6666666	Alignment Tool for Use During Installation (Free)
		· /



## **EXTENSION CABLES**

for use with

## **DSG-TT & DMG-TT**

**SERIES LINEAR ENCODERS** 

